



**electronic rebuilders**

a division of National Parts Distributing Ltd

## *trouble shooting tips*

---

**No. 21 - Installing C2000 Progressive International Consoles**

**Published: May 2002**

**To avoid communication and Totalizer Problems when installing C2000 Progressive International Consoles, perform a Master reset on the Console, and on the Pumps you are connecting it to, before programming the Console and putting it on line.**

**Note! The console must be on line and communicating with the pumps before programming it!**